

## Front Body Panel Guide Set - VW T5

These pins are screwed in place of the front panel mounting bolts to allow the panel to be slid away from the engine without disconnecting all fluid pipes etc.



### Additional Information

- Front body panel guide set.
- Application: Volkswagen Transporter T5 from 2004 onwards.
- Gives essential room without disconnecting fluid pipes etc.
- Equal to OEM T10228. Size M8 x 1.25 x 13mm x 200mm (4 supplied).
- Made in Sheffield

<http://lasertools.co.uk/product/6241>

