

## CV Boot Clamp Pliers 260mm

260mm long CV boot clamp pliers for use on earless clamps. Each jaw has a square end designed to crimp the clamp without cutting it. The spring loaded handle mechanism allows just the right amount of force to be applied for a neat, secure fixing. The pliers have plastic dipped handles for comfort and ease of use. Suitable for securing axle boots on a wide range of vehicles including Audi, BMW, Chrysler, Ford, GM, Honda, Mazda, Mercedes-Benz, Nissan, Porsche, Vauxhall/Opel and VW.



### Additional Information

- Applications: Earless clamps fitted to axle boots on Audi, BMW, Chrysler, Ford, GM, Honda, Mazda, Mercedes-Benz, Nissan, Porsche, Vauxhall/Opel and VW.
- Also suitable for thermoplastic axle boots.
- Long-reach, angled tool handles for more leverage and clamping power.
- Spring loaded handles for control and precision.
- Suitable for use with CV boot clamps, Part Nos. 30881 and 30882.

<http://lasertools.co.uk/product/6737>



