

Camber Adjusting Tool - for VW, Mercedes-Benz

Required tool for shock absorber screw adjustment, to allow for camber adjusting on VW and Mercedes-Benz vans.



Additional Information

- Applications: VW Crafter, Mercedes-Benz Sprinter.
- 21mm Bi-Hex (12pt) profile x 1/2" Drive.
-
-
-

<http://lasertools.co.uk/product/7287>



