

## Shock Absorber Wrench 1/2" D 21mm

Specially shaped shock absorber fitting tool for camber adjustment on Mercedes-Benz Sprinter and Volkswagen Crafter.



### Additional Information

- Applications include: Mercedes-Benz Sprinter & Volkswagen Crafter front suspension.
- Specially shaped tool allows access to shock absorber fitting.
- 1/2" Drive, 21mm, 12pt offset wrench designed for poor access areas.
- Manufactured from Chrome Molybdenum.
- 

<http://lasertools.co.uk/product/7598>



