

Subframe Alignment Pins 4pc - VW T7 Van

Designed to allow the front sub frame on the late model VW T7 Transporter vans to be correctly aligned when refitting after removal. These pins ensure the sub-frame is installed in its original position without the need to carry out wheel alignment checks.



Additional Information

- A set of 4 screw in pins designed to be screwed in to the vehicle chassis to assist in the alignment of the front sub frame.
- Applications include: Volkswagen T7 Transporter, from 2021.
- Equivalent to OEM T50079.
- Use in accordance with OEM instructions.
-

<http://lasertools.co.uk/product/8911>



