

Ball Joint Separator - Scissor Type

For separating ball joints this tool uses the scissor method.



Additional Information

- Jaw size: 30mm (width), 18mm (depth); maximum opening: 50mm.
- Removes ball pin housing on steering arms.
- Steel force screw for leverage.
- Manufactured from carbon steel.
- The tool should not need forcing. If it does, the ball joint will need gently tapping or heating to help separate it.

<http://lasertools.co.uk/product/0282>

