

Sump/Joint Separator

Breaks seals on engine sumps, transmissions or any difficult to separate gasket.



Additional Information

- Blade width: 48mm.
- Simply insert the knurled handle into the separator and tap into joint with a hammer.
- Blade manufactured from SK5 steel.
-
-

<http://lasertools.co.uk/product/5026>



