

## TPMS Torque Driver & Tool Set 6pc

For vehicles fitted with Tyre Pressure Monitoring Systems (TPMS) that rely on sensors attached to the inside of the tyre valve. Designed to remove the valve/sensor unit and dismantle/reassemble in the correct way ensuring that delicate valve components do not get overtightened.



### Additional Information

- Kit includes: 11 & 12mm deep 1/4"D sockets, 1/4"D 100mm extension, torque driver( 2-10Nm ); T-wrench handle, T20 Torx\* bit .
- Low torque driver can also be used for tightening other low torque components eg airbags, interior panels, plastic fairings etc.
- 
- 
- 

<http://lasertools.co.uk/product/5492>



