


## Valve Spring Compressor

Engine valve spring removal kit, can be used with the cylinder head in place if compressed air is used to keep the valves shut (additional components required, Part No. 5258).



### Additional Information

- Complete with 4 valve adaptor sizes - 34, 26, 20, and 18mm covering most modern multivalve engines.
- Supplied with two brackets.
- Can be used in situ with head on for valve spring replacement.
- 
- 

<http://lasertools.co.uk/product/5495>

