



Diesel Injector Extractor with adaptors only

Diesel injector extractor supplied with diesel injector adaptors and accessories for removing most diesel injectors. For use with air hammer (not supplied; Laser part number 6263 includes an air hammer).



Additional Information

- Diesel injector extractor allows effective transmission of impact force and vibration to any adaptor with a 5/8" thread.
- Includes 7 diesel injector adaptors: Siemens (2), Denso, High Pressure M12, Delphi, M16 Denso, Bosch Dual Connection.
- Plus valve seat removal tool for Denso, an off-line injector adaptor for access and a Bosch injector dismantling tool.
- Recommended for use with the Laser air hammer (Part No. 6031).
- Supplied with full instructions. Made in Sheffield to a registered design.

<http://lasertools.co.uk/product/6264>

Video available: <http://youtu.be/wo3CZWMo2nw>

