

Wheel Weight Pliers 5-in-1

This 5-in-1 design allows for the pliers to remove stick-on aluminium wheel weights without touching the surface of the rim, helping avoid damage, along with removing traditional clip-on weights used on steel wheels. It also features a hammer head for refitting or securing new weights and has a removable protective cover for use when fitting new adhesive weights to alloy wheels to prevent damage, together with a clamping function for closing up the hook on clip-on weights to enable them to fit different shaped wheel rims.



Additional Information

- For the removal & installation of wheel weights.
- Suitable for both traditional clip on & adhesive wheel balancing weights.
- Features include: removable hammer head with protective cover, to help prevent damage when using on alloy wheels.
- Cutting edge, for trimming down stick-on wheel weights. Soft grip, spring loaded handles, for ease of use.
- Replacement head available, Part No. 61779. Connect offer a range of wheel weights for steel & alloy wheels, see Part Nos. 32863 - 32872 (steel wheels), 32853 - 32862 (alloy wheels).

<http://lasertools.co.uk/product/8323>

